

Install (2) #6 x 1 1/2" screws at inside top and (2) at inside bottom each corner.

